



1725 DAVIS STREET
ROCKY MOUNT, NC 27803
PH 252-442-2868
FX 252-442-7412
WWW.RODDOORS.COM

INSTALLATION INSTRUCTIONS

ARMREST – MODULAR ABS PLASTIC

Tool Required: (Not included)

Utility Knife
Tin Snips
ABS Pipe Glue
1 Can Contact Cement Spray Glue
Sanding Block (80 grit paper)
Pliers
Tape Measure

Lay out all pieces: (Included)

2 Modular Armrests (1 each driver's and passenger's side)
1 Instruction Sheet

Clear a workspace and assemble all tools needed to complete the installation of your armrest.

Determine the proper location of the armrest. The width of each armrest will vary due to the different size and shape of each style of armrest.

You are covering the armrest and panel separately to be used with door skins, vinyl, cardboard panel systems or when covering the armrest in a different color or material than the door panel itself use the following steps:

- 1) Cut a hole in the door panel large enough for the armrest to fit through allowing an extra 1/8" for the thickness of the fabric.
- 2) Attach the fabric to the armrest with a contact spray adhesive (RodDoors Spray Glue Cheese or 3M Super 90). Spray both the front of the armrest and the back of the fabric letting glue set up for at least 10 minutes and then pressing the two together.
- 3) Fix the armrest in its proper location by either gluing the armrest in place with ABS Cement, or attaching the covered armrest with Dualloc Tabs (not included) or by screwing the armrest to the door.

Thank you for choosing RodDoors, Inc.
www.roddoors.com