



1725 DAVIS STREET  
ROCKY MOUNT, NC 27803  
PH 252-442-2868  
FX 252-442-7412  
[WWW.RODDOORS.COM](http://WWW.RODDOORS.COM)



## Installation Instructions Shake Rattle & Roll Armrest

Once the panel has been trimmed cover the panel same as instructed. Trim back the fabric to within 1/2" of the outline for the armrest.

Trim the armrest and the armrest panel mount (spine) to fit the door panel. Align and trim panel to fit door pull kit at this time if one is to be used.

Mount the armrest panel mount (spine) to the door panel with either screws or pop rivets. This will allow for removal of the armrest itself if you choose to change the fabric later.

Cover the armrest with fabric using the same techniques described in the instructions.

Using ABS pipe glue, apply a liberal coat of glue to the top of the armrest mount (spine) and the underside of the armrest. Press together and weight down the armrest until dry 3 to 4 hours.

HINT: Be EXTREMELEY careful to not get glue onto the fabric. Mask the area not to be glued with plastic sheeting.

**Thank you for choosing RodDoors, Inc. !!**  
**[www.roddoors.com](http://www.roddoors.com)**