



1725 DAVIS STREET  
ROCKY MOUNT, NC 27803  
PH 252-442-2868  
FX 252-442-7412  
[WWW.RODDOORS.COM](http://WWW.RODDOORS.COM)



## Instructions Installation Rear Arm Rests

### Tools required: (Not included)

Utility Knife  
Pliers  
Tin Snips  
Tape Measure  
ABS Pipe Glue  
1 Can Contact Cement Spray Glue  
Sanding Block (80 grit paper)

### System Parts: (Included)

2-rear Arm rests (Passenger's side & Driver's side)

**Clear a workspace and assemble all tools needed to complete the installation of your arm rest.**

First, determine the proper location of the armrest on the rear door panel for height and depth, ensuring there is proper distance between the door panel and the back seat.

**Note:** Standard distance between window and arm rest in most cars is 9" to 11" from the bottom of the glass to the top of the armrest.

**Option#1: If you are covering the arm rest and panel separately to be used with door skins, vinyl, cardboard panel systems or when covering the armrest in a different color or material than the door panel itself.**

A) Cut a hole in the door panel large enough for the armrest to fit through allowing an extra 1/8" for the thickness of the fabric.

B) Attach the fabric to the armrest with a contact spray adhesive. Spraying both the front of the armrest and the back of the fabric letting the glue set up for at least 10 minutes and then pressing the two together.

C) Fix the armrest in its proper location by either gluing the arm rest in place with ABS cement, attaching the covered Armrest with Dualloc Tabs (not included), or screwing the armrest to the door.

**Option#2: If you are covering the panel and armrest with one piece of fabric.**

**Note: this method is intended to be used only with the RodDoors panel system.**

A) Cut a hole in the panel for the armrest to stick through, this time allow an extra ¼" larger than the armrest itself. Then glue the armrest to the back of the panel with A.B.S. pipe cement. The extra large hole in the panel will allow material to flow into the recess around the armrest if necessary.

B) Attach the fabric to the armrests and panels with a contact spray adhesive (RodDoors Spray Glue Cheese or 3M Super 90). Spraying both the armrest/panels and the back of the fabric letting the glue set up for at least 10 minutes and then pressing the two together. Any wrinkles can be removed by lifting the fabric away from the armrests, and re-gluing both armrests and fabric, working the fabric in a different direction the next time.

**Thank you for choosing RodDoors, Inc.!!**

**[www.roddoors.com](http://www.roddoors.com)**