



1725 DAVIS STREET
ROCKY MOUNT, NC 27803
PH 252-442-2868
FX 252-442-7412
WWW.RODDOORS.COM

INSTALLATION INSTRUCTIONS '37-'46 CHEVROLET TRUCK HEADLINER

Tools Required; (Not included)

Utility Knife
ABS Pipe Glue
1 Can Spray Adhesive
Sanding Block (80 grit paper)

Lay out all pieces: (Included)

1 Headliner
1 3' x 4 1/2' Aluminum/Felt Insulation Pad

- 1) Start at the front with the headliner going between the header panel and roof panel. Working from front to back, position the sides of the headliner over the doors and towards the back. At the back the headliner will be positioned behind the rubber seal of the upper back window.
- 2) The sides of the headliner starting from the front will be positioned to the outside of the top of the headliner. Above each door the side of the headliner has 4 holes. If the holes in the headliner don't match the holes in the side panel, new holes can be drilled.
- 3) The quarter panels that go on each side of the back window can now be put in place and secured either with trim screws or tabs on the back of the panels.

Thank you for choosing RodDoors, Inc.
www.roddoors.com