



1725 DAVIS STREET
ROCKY MOUNT, NC 27803
PH 252-442-2868
FX 252-442-7412
WWW.RODDOORS.COM

INSTALLATION INSTRUCTIONS '55-'59 CHEVROLET TRUCK HEADLINER THE KOBI-HEADLINER

Tools Required: (Not included)

Utility Knife
1 Can High Temp Spray Adhesive
1 Can Contact Cement Spray Glue

Lay out all pieces: (Included)

1 Kobi Headline (Smooth or With Design)
1 Tube Clear Liquid Nails
1 Pre-trim Installation Kit
1 Instruction Sheet



Clear a workspace and assemble all tools needed to complete the installation.

- 1) After testing for fit, you're ready to upholster the headliner with fabric. To ensure the entire panel is covered, allow 2 extra inches of fabric around the entire panel. Use only a high temp contact spray adhesive (RodDoors Spray Glue Cheese or 3M Spray Super90). Start in the center; 2 square feet at a time. Take your time. If the fabric has a grain or pattern keep it straight on the center of the panel.
- 2) Any wrinkles can be removed by lifting the fabric away from the panel and re-gluing the panel and fabric. Work the fabric in a different direction the next time.
- 3) Use all the Dualloc tape provided in the installation kit.
- 4) Peel off the red liner on one side of the Dualloc Tab and stick in place on the headliner. (8-10 pieces on the center brackets and the remaining pieces along the edge inner lip of the panel flush to the heat shield approximately 4" to 6" apart.) Remove red liners from opposite side of Dualloc Tabs, apply Clear Liquid Nails (following the directions that were included in your Clear Liquid Nails kit) to sticky side of Dualloc on center bracket only; press the headliner in to place and hold up with a piece of PVC pipe for a couple of hours until everything cures.

Thank you for choosing RodDoors, Inc.
www.roddoors.com