



1725 DAVIS STREET
ROCKY MOUNT, NC 27803
PH 252-442-2868
FX 252-442-7412
WWW.RODDOORS.COM

INSTALLATION INSTRUCTIONS '60-'66 CHEVROLET TRUCK HEADLINER THE KATO/FENNIMAN HEADLINER

Tools Required: (Not included)

1 Can Contact Cement Spray Glue

Lay out all pieces: (Included)

1 Kato/Fenniman Headliner

1 Tube Clear Liquid Nails

1 Pre-trim Installation Kit



Clear a workspace and assemble all tools needed to complete the installation.

1) After testing for fit, you're ready to upholster the headliner with fabric. To ensure the entire panel is covered, allow 2 extra inches of fabric around the entire panel. Use only a high temp contact spray adhesive (RodDoors Spray Glue Cheese or 3M Super 90). Start in the center; spray both the back of the fabric and the front of the panel - 2 square feet at a time. Take your time. If the fabric has a grain or pattern keep it straight on the center of the panel.

2) Any wrinkles can be removed by lifting the fabric away from the panel and re-gluing the panel and fabric; working the fabric in a different direction the next time.

***NOTE: Apply Dualloc tabs (use all tabs provided with the installation kit) to the bracket mounted on the back "smooth" side of your headliner. (Two in the center, one in the front.)

3) Peel off the rid liner from the Dualloc Tab and stick in place on the headliner (8-10 pieces on both the center brackets and the remainder around edge of headliner.) Remove red liners from opposite side of Dualloc tabs, apply Liquid Nails (following the directions that were included in your Liquid Nails Kit), press headliner in place and hold up with a piece of PVC pipe for a couple of hours till everything cures.

**Thank you for choosing RodDoors, Inc.
www.roddoors.com**