



1725 DAVIS STREET
ROCKY MOUNT, NC 27803
PH 252-442-2868
FX 252-442-7412
WWW.RODDOORS.COM



INSTALLATION INSTRUCTIONS

'73 – '87 CHEVROLET TRUCK HEADLINER REPLACEMENT MODEL (REQUIRES ORIGINAL PLASTIC TRIM)

Tools Required: (Not included)

- 1 Can Contact Cement Spray

Lay out all pieces: (Included)

- 1 Dano Headliner
- 1 Tube Clear Liquid Nails
- 1 Pre-trim Installation Kit

Clear a workspace and assemble all tools needed to complete the installation.

- 1) Test for fit, when you are satisfied of the fit, you are ready to upholster the headline with fabric. To ensure the entire panel is covered, allow 2 extra inches of fabric around the entire panel. Use only a high temp contact spray adhesive (RodDoors Spray Glue Cheese or 3M Super 90). Start in the center; spray both the back of the fabric and the front of the panel, 2 square feet at a time. Take your time. If the fabric has a grain or a pattern keep straight on the center of the panel. Any wrinkles can be removed by lifting the fabric away from the panel and re-gluing the panel and fabric, work the fabric in a different direction the second time.
- 2) Peel off the red liner from the Dualloc tab and stick in place on the headliner using 10 to 15 pieces in the center and the remaining pieces along the edge inner lip of the panel. Use all Dualloc tabs provided in the installation kit. Press headliner on to the roof and hold in place with a piece of PVC pipe for a couple of hours until everything cures.

Thank you for choosing RodDoors, Inc.!!
www.roddoors.com