



1725 DAVIS STREET
ROCKY MOUNT, NC 27803
PH 252-442-2868
FX 252-442-7412
WWW.RODDOORS.COM

INSTALLATION INSTRUCTIONS

'76-'87 CHEVROLET TRUCK HEADLINER REPLACEMENT MODEL (Requires Original Plastic Trim)

Tool Required: (Not included)

- 1 Can Contact Cement Spray Glue
- 1 Pair Scissors

Lay out all pieces: (Included)

- 1 Dano Headliner
- 1 Pre-trim Installation Kit
- 1 Instruction Sheet

Clear a workstation and assemble all tools needed to complete the installation.

- 1) Test for fit, when you're satisfied of the fit you are ready to upholster the headliner with fabric. To ensure the entire panel is covered, allow 2 extra inches of fabric around the entire panel. Use only a high temp contact spray adhesive (RodDoors Spray Glue Cheese or 3M Super 90). Start in the center, spray both the back of the fabric and the front of the panel; 2 square feet at a time. Take your time. If the fabric has a grain or pattern keep it straight on the center of the panel.
- 2) Any wrinkles can be removed by lifting the fabric away from the panel and re-gluing the panel and fabric, working the fabric in a different direction the next time.
- 3) Peel off the red liner from the Dualloc Tab and stick in place on the headliner (10-15 pieces in the center and the remaining pieces along the edge inner lip of the panel. Use all Dualloc Tab provided in the installation kit. Press headliner onto the roof using a piece of PVC pipe to hold in place for a couple of hours until everything cures.

Thank you for choosing RodDoors, Inc.
www.roddoors.com