



1725 DAVIS STREET
ROCKY MOUNT, NC 27803
PH 252-442-2868
FX 252-442-7412
WWW.RODDOORS.COM



INSTALLATION INSTRUCTIONS

Dash Extension/ Overhead Wiper Cover

Tools required: (Not included)

Utility Knife
ABS Cement
1 Can Spray Adhesive
Sanding Block (80 grit)

Lay out all pieces: (Included)

1 7" x 7" x 48" Cover
2 RADIUS CORNERS
5 1" x 1" x 4" L BRACKETS
1 Bag of Dualloc Tabs

Installation of either use can be broken down into the three following sections.

1. Locating: Lay out all required materials, use the cardboard box as a template and trim to the rough finished size for either a dash extension or an overhead wiper cover console.

2. Trim and Glue:

Transfer the pattern from the cardboard to the plastic cover, scoring the plastic with a sharp utility knife. Breaking off the excess like you would tile or wall board. Test for fit. Try to stay large and work your way to size. If somehow you've cut the panel to small you can always glue more material onto the cover using ABS pipe cement and the formerly excess material. Continue cutting out for any vents, radios, and storage pockets. Block sand smooth any rough edges with 80 grit sandpaper. Trim side panels to size. Glue side panels to the ends of the cover. Let dry over night. Sand off any excess glue till smooth. Fill any holes with additional pipe cement.

NOTE: Cover should be trimmed to size—then subtract the depth of the corners, for the final trim width, prior to gluing.

3. Cover and Install: Press on 1/8" RodFoam or any other padding material if desired. Glue on your choice of fabrics, using a contact spray adhesive (RodDoors Spray Glue Cheese or 3M Super 90). Trim off any excess fabric.

Note: For a tighter fit as either a dash extension or as a wiper cover, fill in the area that is between the ends of the cover and the sides of the car with either RodFoam or its equivalent.

Press cover into place using brackets and Dualloc Tabs provided in the kit.

Thank you for choosing RodDoors, Inc.!!
www.roddoors.com