



1725 DAVIS STREET  
ROCKY MOUNT, NC 27803  
PH 252-442-2868  
FX 252-442-7412  
[WWW.RODDOORS.COM](http://WWW.RODDOORS.COM)



## **INSTALLATION INSTRUCTIONS DIRECT MOUNT BENCH SEAT**

1. Position seat back to the back of the cab. Mark the upper location of the seat back using masking tape. Measure the distance from the top of the seat to the bracket (black ones) support hole at the top of the seat. Drill pilot holes in cab braces and screw brackets in place. Mount seat back onto the upper brackets. Put lower brackets (silver ones) onto lower seat back tubing and locate mounting holes. Drill pilot holes and screw the lower brackets in place.
2. Place seat base in position on original riser, adjust lower seat base positioning bracket tight to the front base frame. This will keep seat base from traveling all over the truck interior while driving.
3. Lower rear quarters into position above seat, release tension on rear, allow rear to find its own position and enjoy your new ride.

**Thank you for choosing RodDoors, Inc.!!**  
**[www.roddoors.com](http://www.roddoors.com)**