



1725 DAVIS STREET  
ROCKY MOUNT, NC 27803  
PH 252-442-2868  
FX 252-442-7412  
[WWW.RODDOORS.COM](http://WWW.RODDOORS.COM)



## Installation Instructions

### '64 ½ - '66 Ford Mustang Deck Lid

#### **Tools required: (Not included)**

1-Can Contact Cement Spray Glue

#### **Lay out all pieces: (Included)**

- 1 '64 ½ -'66 Mustang Deck Lid
- 1 Bag of Dualloc Tabs

Clear a workspace and assemble all tools needed to complete the installation.

1) After testing for fit, you're ready to upholster the Deck Lid with fabric. To ensure the entire panel is covered, allow 2 extra inches of fabric around the entire panel. Be sure to use only a high temp contact spray adhesive (RodDoors Spray Glue Cheese or 3M Super 90). Start in the center: spray both the back of the fabric and front of the panel—2 square feet at a time. Take your time. If the fabric has a grain or a pattern keep it straight on the center of the panel. Any wrinkles can be removed by lifting the fabric away from the panel, re-gluing the panel and the fabric, let dry then rework the fabric in a different direction the next time to keep out any wrinkles.

#### **Note:**

Use all the Dualloc Tabs provided in the installation kit.

2) Peel off the red liner from the Dualloc Tab and stick in place on the Deck Lid use 5-8 pieces in the center above the latch and the remaining pieces along the edge of the trunk lid. Remove the red liner opposite side and press the Deck Lid into place.