



1725 DAVIS STREET
ROCKY MOUNT, NC 27803
PH 252-442-2868
FX 252-442-7412
WWW.RODDOORS.COM



INSTALLATION INSTRUCTIONS FORD '67-'68 MUSTANG DECK LID

Tools required: (Not included)

- 1 Can Contact Cement Spray Glue

Lay out all pieces: (Included)

- 1 '67-'68 Mustang Deck Lid
- 1 Bag Dualloc Tabs

Clear a workspace and assemble all tools needed to complete the installation.

1) After testing for fit, you are ready to upholster the deck lid with fabric. To ensure that the entire panel is covered, allow 2 extra inches of fabric around the entire panel. Be sure to use only a high temp contact spray adhesive (RodDoors Spray Glue Cheese or 3M Super 90). Start in the center; spray both the back of the fabric and the front of the panel – 2 square feet at a time. Take your time. If the fabric has a grain or a pattern keep it straight on the center of the panel. Any wrinkles can be removed by lifting the fabric away from the panel, re-gluing the panel and the fabric, let dry, then rework the fabric in a different direction.

Note: Use ALL Dualloc Tabs provided in the installation kit.

2) Peel off the red liner from the Dualloc tab and stick in place on the deck lid, 5-8 pieces in the center above the latch and the remaining pieces along the edge of the trunk lid. Remove the red liner on the opposite side and press the deck lid into place

Thank you for choosing RodDoors, Inc.!!
roddoors.com